

4600 FabriVISION

PART NUMBER	DESCRIPTION
757	Cycle Start Bulb
800T-X504	Red Emerg. Stop Plate
M15D014	Bracket, Sensor
800T-N41	Lens, Green
M10D012	Cable/Snap Link
M10EC06	Array Adaptor Cable
800T-X559E	Legend Plate, Cycle Ready
800MR-W100E	Legend Plate, Motor
800MRW100E	Legend Plate, 3 Pos.
M50EC11-2	Ground Cable
M15EC10	Motor Encoder Cable
4715-12T-B40	Fan, Pull
4715-12T-B50	Fan, Push
R10-E1-X4-V185	Relay, Four Pole 12V
32-27-ZP	Leveling Feet
R10-E1-X4-V700	Relay, Four Pole 24V
M15EC13-2	Light Sensor/Cable
M15EC13-1	Ready Light Cable
700-CF400D	Relay, Type F
800T-A1A	Cycle Start Switch
700-F310A1	Relay, Type F
HB24-1.2-A	24V Power Supply
M15EC04	Fan, AC Power
800T-Q24G	24V Pilot Light
M20D004	Rack Mod 2 Short
800T-D6B	Button, Mushroom Head
800MR-24JX9U	Switch, Selector 3 pos.
800MR24JX9U	3 Pos. Operator Switch
M50EC10	Carriage Power Cable
M10CB04	DC Power Panel
M10EC01	Video Power Cable, Set
M50EC23	Main Power Cable
HBAA-40-W-A	Power Supply
800T-QAL24G	Cycle Start Button Assy
M10D014	Curtain, Camera
M20CB02	RS-232 Booster Circuit
M10CB02	Array Adaptor PCB
M10EC02	Array Adaptor Board
M15CB01-A	Signal Distribution PCB
M15CB01-B	Signal Distribution PCB
M20D003	Rack Mod 1 Long
HDBB-105W-A	Power Supply
M10EC04	Video/Mux Ribbon Cable, Set
M50EC24	Power Strip Mod
M35D011	Divider Assy
M50EC22	External Computer Cable
M50EC21	Internal Computer Cable
M10CB03	Multiplexer
FX0696-4-120	Ballast, Adjustable

M15D013	Gearmotor w/ Encoder
M20CB03	4600Servo Amp Board
M10CB01-A	Camera Board, Top Mount
M10CB01-B	Camera Board, Side Mount
M50CB01	Processor Board
M10CB05	Single camera board array
OPTO-22	4600 Board for Operator
390-1	Lamp Base
MCC1	Mini Motion Control

4800 FabriVISION

<u>PART NUMBER</u>	<u>DESCRIPTION</u>
757	Start Switch Bulb
554148	Fan Guard, w/Filter
Gas Shocks	Gas Shocks for older 4800
4715-12T-B40	Fan, Pull
4715-12T-B50	Fan, Push
BZ-2RQ1872-A2	Limit Switch
32-74-ZP	Leveling Feet
JLX-514	CCD Array
ZB2-BW33/ZB2-BW061 ZB2-BE101	Start Switch Assy
ZB2-BS54/ZB2-BZ102	E-Stop Switch Assy.
J10EC03	Ground, Chassis/Camera
J10EC04	Ground, Door/Chassis
J10EC05	Ground, Camera/PCB
J30D009	Glass Scale Hold Down Mod.
J10D015	Camera Curtain
J30EC02	Cable, Motor Power
J20EC02	Cable, Fans R.H.
J20EC04	Cable, Fans L.H.
J10CB02	Array Adapter Board
CP503-A	Power Supply 5/12/24 volt
J20EC06	Cable, (Sets) Stop R.H.
J20EC07	Cable, (Sets) Stop L.H.
J30EC06	Cable, Ballast LED
J30EC07	Cable Sensor
J40EC03	Main Power Switch assy. W/ fuse and filter
J25D101	Ring, PC Mount (CCD)
J10EC02	Cable, Set Mux/Camera
J40EC01	Cable, Computer, Internal
210 NIKON LENS	NIKON Lens(50mm)
J40EC01-S	Cable, Computer, Internal, Stretch
J50EC01	Cable, Computer External
S model crate	80 X 70 X 78
J10CB03 Rev. 1	Linear Encoder Signal Board
L model crate	80 X 180 X 78
FX0696-4-120	Ballast, Adjustable

J35D001	Y-Axis Glass Scale
M15D013	Gear Motor Mod
Glass Scale Retro Kit	Glass Scale Retro Kit
J50CB01	Processor Board, Main
J30D043	"Y" Axis Scale, Wide
J10CB01 Rev. 3	Motion/Signal Board
J10CB01 Rev. 4	Motion/Signal Board
390-1	Lamp Base
5765-18212	Fuse, 2.5 AMP
GL 1000 9637	13C-0702
GL 1000 9636	13C-0702A
GL 1000 9703	13C-0704A
GL 1000 9707	13C-0705
GL 2010 Rev.H	
MS51-368/L120/3M	Read Head (RSF)
J35D002	Glass Top, S-model
J35D002-S	Glass Top, L-model
J50EC02	Cable, AC power